

DART AEROSPACE LTD	Work Order:	18869
Description: Custom W/O Brackets Modification	Part Number:	D3121-041/-043/ -045/-046
Dwg: D3121 Rev. B pages 1, 4, 5, 6	Qty:	1
		Page 1 of 2

Step	Location	Procedure	By	Date	Qty																																
1	DC	Issue Traveler	HA	03.02.29	1																																
2	PK ST # 03.02.29	Pick: <table><thead><tr><th>Qty</th><th>Part Number</th><th>Description</th><th>Batch</th></tr></thead><tbody><tr><td>5</td><td>B32-23001-11</td><td>Bracket</td><td>M10536-17</td></tr><tr><td>2</td><td>B32-23001-13</td><td>Bracket</td><td>M10536-17</td></tr><tr><td>2</td><td>B32-23001-15</td><td>Bracket</td><td>M10536-17</td></tr><tr><td>1</td><td>B32-23001-16</td><td>Bracket</td><td>M10536-17</td></tr><tr><td>12 15</td><td>D3121-17</td><td>Washer</td><td>M10536-17</td></tr><tr><td>12 15</td><td>D3121-19</td><td>Bearing</td><td>B17458</td></tr><tr><td>12 15</td><td>MS24694S50</td><td>Screw</td><td>B11735</td></tr></tbody></table>	Qty	Part Number	Description	Batch	5	B32-23001-11	Bracket	M10536-17	2	B32-23001-13	Bracket	M10536-17	2	B32-23001-15	Bracket	M10536-17	1	B32-23001-16	Bracket	M10536-17	12 15	D3121-17	Washer	M10536-17	12 15	D3121-19	Bearing	B17458	12 15	MS24694S50	Screw	B11735	SL	03/07/09	1
Qty	Part Number	Description	Batch																																		
5	B32-23001-11	Bracket	M10536-17																																		
2	B32-23001-13	Bracket	M10536-17																																		
2	B32-23001-15	Bracket	M10536-17																																		
1	B32-23001-16	Bracket	M10536-17																																		
12 15	D3121-17	Washer	M10536-17																																		
12 15	D3121-19	Bearing	B17458																																		
12 15	MS24694S50	Screw	B11735																																		
3	MV	Machine B32-23001-11 into D3121-11 per Dwg D3121 page 4. Remove Premier ID and scribe with Dart P/N and B/N. Deburr edges	SL	03/07/09	1																																
4	QC2	Inspect parts as they come off the CNC machine	SL	03/07/09	1																																
5	QC8	Second check	FL	03/07/09	1																																
6	MV	Machine B32-23001-13 into D3121-13 per Dwg D3121 page 5. Remove Premier ID and scribe with Dart P/N and B/N. Deburr edges	SL	03/07/09	1																																
7	QC2	Inspect parts as they come off the CNC machine	SL	03/07/09	1																																
8	QC8	Second check	FL	03/07/09	1																																
9	MV	Machine B32-23001-15 into D3121-15 per Dwg D3121 page 6. Remove Premier ID and scribe with Dart P/N and B/N. Deburr edges	SL	03/07/09	1																																
10	QC2	Inspect parts as they come off the CNC machine	SL	03/07/09	1																																
11	QC8	Second check	FL	03/07/09	1																																
12	MV	Machine B32-23001-16 into D3121-16 per Dwg D3121 page 6. Remove Premier ID and scribe with Dart P/N and B/N. Deburr edges	SL	03/07/09	1																																
13	QC2	Inspect parts as they come off the CNC machine	SL	03/07/09	1																																
14	QC8	Second check	FL	03/07/09	1																																
15	MV	Assemble D3121-11 per Dwg D3121 page 1	SL	03/07/09	1																																
16	QC5	Inspect D3121-11 work to step 15	SL	03.07.09	1																																